Telemecanique Sensors

AC441AUS North American Configuration Kit

AC441AUS Bill of Materials

Qty	Item	
1	AC441A	Handheld Configurator Module
1	109268	Wall mounting tabs set
1	112347	Inline AC-to-DC Supply
1	109766	North American 110 Volt Outlet supply cord
1	109887	Superprox+CD (Software and Instructions)
1	XZCPVB1141L1	3-foot (1m), 4-pin M12 cable, Shielded
1	XXZAC1303PB	3-foot (1 m), 4-pin M12 cable with 109252 plug
1	XXZAC1303PW	3-foot (1 m), 4-pin M12 cable with 109252 plug
1	XXZAC137	8 inch (0.2 m),4-pin M8-to-M12 adaptor cable
1	AC172	6-foot (2 m), DB9-to-RS232 cable
1	XXZAC125	USB-to-RS232 adaptor + Install CD
1	AC441A-xKit	List of Sensor models used with XXZAC130PB and PW

Install the Superprox+ software on your computer. An .exe software file will be created, along with a .pdf Software Instruction booklet. Please review this booklet prior to utilizing the software.

If your computer has a DB9 RS-232 port, use the AC172 cable. If it uses a USB port, you may need to connect the XXZAC125 adaptor to the AC172 to use your USB port. The AC125 includes a Driver CD to support the USB port adaptor. Please install per the instructions on the CD.

The XXZAC1303PB and XXZAC1303PW cables have 4-pin M12 connectors for the sensor and plug-in connectors to the AC441A connector. The XZCPVB1141L1 can also be used on all SC/VC/XX configurable sensors with connectors. If your sensor has a 4-pin M8 connector, use the AC137 Adaptor cable along with these cables to provide the M8 connection to your sensor. Sensors with 3-pin M8 connectors require a 3-pin Fem M8-to-M12 4-pin Male jumper cable (not supplied).

The attached sheets list which SC/VC/XX configurable sensors are used with these cables.

For assistance contact:

Sensor Competency Center Support Group
800-435-2121 Option 2.

XXZAC1303PW Sensor Programming Cable

Use With The Following Sensors:

SC340A400+FP
SC350A400+FP
SC380A400+FP
SC390A400+FP
SC650AB00+FP
VC1/18 NPN
(Disconnect White wire)
XX512B…M12
XX512B…N12
XX518B1
XX518B3
XX7F1B…M8
XX7F1B…M12
XX7K1B

XXZAC1303PB Sensor Programming Cable

Use With The Following Sensors:

SC330A400+FP
SC3A0A400+FP
SC360A400+FP
SC390A400+FP
SC656ABC0/BV0+FP
SC660AB00+FP
SC690AB00+FP
SC950A100,400,800
SC956A1C0/1V0
SC956A4C0/4V0
SC956A8C0/8V0
VC1/18 V/C or PNP
(Disconnect White wire)
XX512B
XX518B…N12
XX518B3
XX630B
XX7F1B…N8
XX7K1B…N12
XX7V1B
XX918B
XX918B3
XX930B
XX930T
XX9K1B
XX9V1B