

Technical data sheet Mobile bar code reader

Part no.: 50127898

IT 1280i FR-3



Contents

- Technical data
- Electrical connection
- Operation and display
- Notes
- Accessories



Technical data



Basic data	
Series	IT128xi
Read data	
Code types, readable	2/5 Interleaved
	Codabar
	Code 128
	Code 39
	Code 93
	EAN 128
	EAN 8/13
	EAN Addendum
	GS1 Databar
	GS1 Databar Expanded
	GS1 Databar Limited
	GS1 Databar Omnidirectional
	GS1 Databar Stacked
	GS1 Databar Truncated
	Others on request
	UPC
Optical data	
Reading distance	100 4,460 mm
Light source	Laser
Bar code contrast (PCS)	35 %
Electrical data	
Performance data	4
Supply voltage U _B Power consumption, max.	4 5.5 V, DC 1.8 W
Fower consumption, max.	1.0 VV
Interface	
Туре	PS/2, RS 232, USB
RS 232	
Function	Process
USB	
Function	Process

Type of connection	RJ41
Mechanical data	
Dimension (W x H x L)	133 mm x 195 mm x 75 mm
Housing material	Plastic
Plastic housing	UL 94-V0
Net weight	335 g
Environmental data	
Ambient temperature, operation	-30 50 °C
Ambient temperature, storage	-40 70 °C
Relative humidity (non-condensing)	0 95 %
Drop height	2 m
Measurements relative to	Concrete floor
0.05.0	
Certifications	
Degree of protection	IP 65
	33
Classification	
Classification Customs tariff number	84719000
Classification Customs tariff number ECLASS 5.1.4	84719000 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0	84719000 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0	84719000 27280101 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0	84719000 27280101 27280101 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0	84719000 27280101 27280101 27280101 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101 EC002550
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0 ETIM 6.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0 ETIM 6.0 ETIM 7.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101 EC002550
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0 ETIM 6.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101 EC002550 EC002550
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0 ETIM 6.0 ETIM 7.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101 EC002550 EC002550 EC002550
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0 ETIM 6.0 ETIM 7.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101 EC002550 EC002550 EC002550
Classification Customs tariff number ECLASS 5.1.4 ECLASS 8.0 ECLASS 9.0 ECLASS 10.0 ECLASS 11.0 ECLASS 12.0 ECLASS 13.0 ETIM 5.0 ETIM 6.0 ETIM 7.0	84719000 27280101 27280101 27280101 27280101 27280101 27280101 27280101 EC002550 EC002550 EC002550


Connection 1

Electrical connection

Connection 1

Function	Configuration interface
	Data interface
Type of connection	RJ41

Pin	Pin assignment
1	Shield
2	Cable ID
3	GND
4	TxD RS 232 / n.c. USB



Electrical connection



Pin	Pin assignment
5	RxD RS 232 / n.c. USB
6	CTS RS 232 / n.c. USB
7	+5 V DC
8	RTS RS 232 / n.c. USB
9	n.c. RS 232 / Data + USB
10	n.c. RS 232 / Data - USB

Operation and display

LED	Display	Meaning
1	Green, 1x flashing	Reading successful
	Red	Operational readiness

Notes



ATTENTION! LASER RADIATION - CLASS 2 LASER PRODUCT



Do not stare into beam!

The device satisfies the requirements of IEC 60825-1:2007 (EN 60825-1:2007) safety regulations for a product of **laser class 2** as well as the U.S. 21 CFR 1040.10 regulations with deviations corresponding to Laser Notice No. 50 from June 24, 2007.

- Never look directly into the laser beam or in the direction of reflected laser beams! If you look into the beam path over a longer time period, there is a risk of injury to the retina.
- ♦ Do not point the laser beam of the device at persons!
- 🖖 Interrupt the laser beam using a non-transparent, non-reflective object if the laser beam is accidentally directed towards a person.
- ♥ When mounting and aligning the device, avoid reflections of the laser beam off reflective surfaces!
- 🔖 CAUTION! Use of controls or adjustments or performance of procedures other than specified herein may result in hazardous light exposure.
- Observe the applicable statutory and local laser protection regulations.
- The device must not be tampered with and must not be changed in any way. There are no user-serviceable parts inside the device. Repairs must only be performed by Leuze electronic GmbH + Co. KG.

NOTE



Affix laser information and warning signs!

Laser information and warning signs are affixed to the device. In addition, self-adhesive laser information and warning signs (stick-on labels) are supplied in several languages.

- Affix the laser information sheet to the device in the language appropriate for the place of use. When using the device in the US, use the stick-on label with the "Complies with 21 CFR 1040.10" note.
- Affix the laser information and warning signs near the device if no signs are attached to the device (e.g. because the device is too small) or if the attached laser information and warning signs are concealed due to the installation position.
- Affix the laser information and warning signs so that they are legible without exposing the reader to the laser radiation of the device or other optical radiation.

Accessories



Connection technology - Connection unit

	Part no.	Designation	Article	Description
1	50112891	MA 248i Profinet Gateway	Modular connection unit	Supply voltage: 18 30 V Current consumption, max.: 300 mA Interface: PROFINET, RS 232 Connections: 6 Piece(s) Degree of protection: IP 65

Connection technology - Interconnection cables

Part no.	Designation	Article	Description
50113397	KB JST-HS-300	Connection cable	Suitable for interface: RS 232 Connection 1: JST ZHR Connection 2: Sub-D, Axial, Male, 9 -pin Shielded: Yes Cable length: 300 mm Sheathing material: PUR

Connection technology - Y distribution cables

Part no.	Designation	Article	Description
50114517	KB 232-1 IT190x	Interconnection cable	Suitable for interface: RS 232, TTL Connection 1: RJ41 Connection 2: Sub-D, Axial, Female, 9 -pin Connection 3: Connector, Pluggable, Axial, Female, 2 -pin Shielded: Yes Cable length: 3,000 mm Sheathing material: PVC

Mounting technology - Other

Part no.	Designation	Article	Description
50120444	BT Wallholder HS65x8	Wall mount	Design of mounting device: Wall mounting Fastening, at system: Through-hole mounting Mounting bracket, at device: insertable Material: Plastic

Note



🖔 A list with all available accessories can be found on the Leuze website in the Download tab of the article detailed page.